

Assembly instruction

Installation – made easy



Depending on the fixing method, either screw in securing anchors in each window corner or drill holes in the side of the frame (corner distance approx. 15 cm).



Place the window in the wall opening, align it with the spirit level and fix it in the corners with wedges. Then carefully perform a function check.



Remove the casement. Drill and screw through the wall anchor or the frame into the masonry. Reinsert the casement.



Insulate the cavities with non-pressing foam (frame foam).



After hardening, cut off the excess installation foam with a sharp knife.



Cover joints vapour-tight inside and driving rain-tight and diffusion-open on the outside. Finally, clean the new window.