

# ACO shoe scraper systems for outdoor and indoor use

## Easy installation, perfect solutions

### Floor channel system for outdoor use

The ACO shoe scraper system Vario for outdoor use absorbs even the coarsest dirt and moisture. Installation is very easy, as only prefabricated elements are used - which is particularly interesting for DIY projects.



1 Prepare the substrate so that the upper edge of the ACO shoe scraper Vario is flush with the adjacent surface covering. (important for the following steps!)



2 Place and align the floor tray of the shoe scraper on the substrate.



3 Insert the shoe scraper mat or the cover grating and check that it is firmly in place.



4 Then work on the adjoining surface covering.

When connecting to the sewage system, use a PVC pipe (DN 100). The drainage connection makes it more difficult for water to enter your house.

## Easy installation, perfect solutions

### Angled frame system for interior use

The ACO indoor shoe scraper system gives dirt in the corridor no chance. The advantage for you: less work, plus reliable protection for your floor coverings. Installation is easy and takes place directly into the wet tile adhesive.



Place the angle frame on the prepared tile adhesive, align and press on.



To create a flat support for the mat, apply tile adhesive evenly to the lower edge of the frame.



Then work on the floor covering. Allow for a narrow expansion joint.



Finally, place the indoor shoe scraper mat into the angle frame after it has dried.

### ACO Hochbau Vertrieb GmbH

Neuwirtshauser Straße 14, 97723 Oberthulba/Reith  
Tel. 09736 41-60, Fax 09736 41-52  
hochbau@aco.com  
www.aco-hochbau.de

**ACO. creating  
the future of drainage**

